

SWIX VALLATIPS INFÖR VASALOPPSVECKAN

GÄLLANDE MÅNDAG 23.02.2015

Detta vallatips är baserat på väderleksprognoser och tester.

TEMPERATURPROGNOS

Sälen	kl. 14.00	-1°C
Evertsberg	kl. 14.00	-2°C
Mora	kl. 14.00	+1°C

STRUKTUR

Stenslipade skidor: Medium. Kom ihåg att rill ovanpå stenslip ofta ger bättre glid.

Swix Rilljärn: 1,00 mm rätt (vals som präglar en rätt struktur) (T423/T406).

GLID - Alternativ 1:

1. Värm in LF8X, låt kallna. Värm in en gång till, efter avkyllning sickla av med plexisickel och borsta med Swix brons- eller stålborste.
2. Avsluta med Swix blå nylon poleringsborste.

GLID - Alternativ 2 - racing:

1. Värm in HF8X låt kallna. Värm in en gång till, efter avkyllning sickla av med plexisickel och borsta med Swix brons- eller stålborste.
2. Lägg på Cera F FC8X. Använda vallajärn på ca 165°C. För järnet i en rörelse på var sida om styrspåret. Vänta därefter i ca 5 minuter och borsta upp Cera F pulvret från belaget med en styv, svart nylonborste. Borsta bort från belaget med en hästhårs- eller vildsvinsborste.
3. Avsluta med Swix blå nylon poleringsborste.

FÄSTE:

1. Rugga fästzonen med slippapper #100 (Swix T330 el. T0011)
2. Spraya på ett lager KB20 grundklister.
3. Lägg på ett lager K21S silver universalklister.

Detta var dagens vallarekommendation för Vasaloppsspåren.

Det har kommit lite nysnö under natten och morgonen. Vallatipset förutsätter att spåren är dragna idag.

LYCKA TILL!

SWIX WAX TIPS FOR THE VASALOPPET WEEK

FOR MONDAY 23.02.2015

These wax tips are based on weather prognoses and testing.

TEMPERATURES

Sälen	kl. 14.00	-1°C
Evertsberg	kl. 14.00	-2°C
Mora	kl. 14.00	+1°C

STRUCTURE

Stone ground skis: Medium structure.

Remember to use hand structure on stone ground skis for better glide.

Swix Structure Tools: Imprint Tool Roller (T423/T406) "Straight": 1.00 mm (imprint roller that gives straight structure)

GLIDE - Alternative 1:

1. Iron in LF8X. Let cool off. Iron in once more and let cool off. Scrape off with a Swix Plexi Scraper, and brush with a Swix Bronze or Steel Brush.
2. Finish with the Blue Nylon Polish Brush.

GLIDE - Alternative 2:

1. Iron in one layer of HF8X. Let cool off. Iron in once more and let cool off. Scrape off with a Swix Plexi Scraper, and brush with a Swix Bronze or Steel Brush.
2. Apply Cera F FC8X with an iron temperature of approx. 165°C. Make one continuous pass with the iron with a constant pressure – take one side of the groove at the time. Let cool approx. 5 min. Brush up the powder with a stiff, black nylon brush. Continue brushing with a horsehair- or wild boar brush.
3. Finish with the Blue Nylon Polish Brush.

GRIP:

1. Sand (rub) the grip zone area with #100 grit silicon sandpaper (Swix T330 or T0011).
2. Spray on a thin layer of KB20 Base klister.
3. Apply a layer of K21S Universal klister.

This is our recommendation for today's conditions in the Vasaloppet track.

There has been little new snow during the night and morning. Contain tip assumes that the tracks are routed today.

We wish everybody a nice trip!



RACING SERVICE
swix®