

SWIX RACING VALLATIPS VASALOPPET

GÄLLANDE SÖNDAG 03.03.2019

Detta vallatips är baserat på väderleksprognoser från smhi och på tidigare testning. Det är spot snö från i natt och ut över hela dagen. Utifrån tidigare erfarenhet är det inte aktuellt med klister i dessa förhållanden.

TEMPERATURPROGNOS

Sälen	kl. 08.00	-4°C
Evertsberg	kl. 11.00	-3°C
Mora	kl. 14.00	-2°C

STRUKTUR

Stenslipade skidor: Medium. Kom ihåg att rill ovanpå stenslip ofta ger bättre glid.

SWIX Rilljärn: 1,00 mm rätt med lätt tryck (vals som präglar en rätt struktur).

GLID - Alternativ 1

1. Värm in **Vit Marathon** låt kallna. Värm in en gång till, efter avkyllning sickla av med plexi sickel och borsta med SWIX brons- eller stålborste. Detta för att få bättre slitstyrka
2. Spraya på **HF8XL Liquid**, låt torka. Applicera vid en temperatur över 10°C. Var noga med att det torkar minst 15 minuter.
3. Avsluta med SWIX blå nylon poleringsborste.
4. Lägg på **Cera F FC8X**. Använda valljärn på ca. 165°C. Dra järnet snabbt över belaget. Vänta i ca. 10 min. och borsta bort från belaget med en hästhårs- eller vildsvinsborste.
5. Avsluta med SWIX blå nylon poleringsborste

GLID - Alternativ 2

1. Värm in **Vit Marathon** låt kallna. Värm in en gång till, efter avkyllning sickla av med plexi sickel och borsta med SWIX brons- eller stålborste.
2. Lägg på **Cera F FC8X**. Använda valljärn på ca. 165°C. Dra järnet snabbt över belaget. Vänta i ca. 10 min. och borsta bort från belaget med en hästhårs- eller vildsvinsborste.
3. Avsluta med SWIX blå nylon poleringsborste.

FÄSTE

1. Rugga fästzonen med slippapper #100 (SWIX T330 el. T0011).
2. Värm på ett lager **VG35** grönt grundvax. Låt kalna
3. Värm in ett lager **V30** blå burk, låt kallna.
4. Lägg 4-6 tunna lager **VR45** lila burk.
5. Justera med **VR50** vid bakhalt
6. Kan vara bra att ta med på turen.
VX63 alt VR55N vid bakhalt, skrapa och kloss

SKIN-SKIDOR

Skall Du åka med **skin-skidor**, rengör först med **N18 SWIX Skin Cleaner PRO**, därefter impregnerar du skinytan med **N17C SWIX Skin Care PRO Cold**.

LYCKA TILL!

SWIX RACING WAX TIPS FOR VASALOPPET

FOR SUNDAY MARCH 03, 2019

This wax tip is based on weather forecasts from smhi and on previous testing. It is predicting snow from night and out all day. Based on previous experience, there is no need for adhesive in these conditions

TEMPERATURES

Sälen	kl. 08.00	-4°C
Evertsberg	kl. 11.00	-3°C
Mora	kl. 14.00	-2°C

STRUCTURE

Stone ground skis: Medium. Remember to use hand structure on stone ground skis for better glide.

SWIX Structure Tool: 1.0 mm linear structure (imprint roller that gives straight structure).

GLIDE: Alt. 1

1. Iron in one layer of **White Marathon**. Let cool off. Iron in once more and let cool off. Scrape off with a Plexi Scraper, and brush with a SWIX Bronze or Steel Brush. This to get better wear resistance.
2. Spray on **HF6XL Liquid** and let dry for at least 15 minutes. Apply the product in temperatures above 10°C. To obtain the best performance it's important to allow the wax film to dry entirely.
3. Finish with the SWIX Blue Nylon Polish Brush.
4. Apply **Cera F FC8X**. Iron temperature of approx. 165°C. Make one continuous pass with the iron with a constant pressure – take one side of the groove at the time. Let cool approx. 10 min. Brush up the powder with a stiff, black nylon brush. Continue brushing with a horsehair- or wild boar brush.
5. Finish with the SWIX Blue Nylon Polish Brush.

GLIDE: Alt. 2

1. Iron in one layer of **White Marathon DHF104**. Let cool off. Iron in once more and let cool off. Scrape off with a Plexi Scraper, and brush with a SWIX Bronze or Steel Brush.
2. Apply **Cera F FC8X**. Iron temperature of approx. 165°C. Make one continuous pass with the iron with a constant pressure – take one side of the groove at the time. Let cool approx. 10 min. Brush up the powder with a stiff, black nylon brush. Continue brushing with a horsehair- or wild boar brush.
3. Finish with the SWIX Blue Nylon Polish Brush.

GRIP: For todays conditions

1. Sand (rub) the grip zone area with #100 grit silicon sandpaper (Swix T330 or T0011).
2. Iron in one layer of **VG35** Green Base Binder. Let cool off.
3. Iron in one layer of **V30** Blue Grip Wax. Let cool of.
4. Apply 4-6 **thin** layers of **VR45** Purpel Grip Wax. Smooth carefully out between each layer.
5. Adjust with **VR50** if slippery
6. Can be good to bring along the tour.
VX63 alt VR55N if it's slippery, scraper and block

SKIN SKIS

If you are using **skins with integrated skins** we recommend to clean the skins with **N18 SWIX Skin Cleaner PRO** and then use **N17C SWIX Skin Care PRO Cold** to improve the skins glide properties.

We wish everybody a nice trip!



Swix Racingservice Norge // Swix Sverige

