



## SWIX FLUOR FRITT VALLATIPS VASALOPPET

**GÄLLANDE SÖNDAG 03.03.2019**

Detta vallatips är baserat på väderleksprognoser från smhi och på tidigare testning. Det är spot snö från i natt och ut över hela dagen. Utifrån tidigare erfarenhet är det inte aktuellt med klister i dessa förhållanden

### TEMPERATURPROGNOS

Sälen	kl. 08.00	-4°C
Evertsberg	kl. 11.00	-3°C
Mora	kl. 14.00	-2°C

### STRUKTUR

**Stenslipade skidor:** Fin till medium. Kom ihåg att rill ovanpå stenslip ofta ger bättre glid.

**SWIX Rilljärn:** 1,00 mm rätt struktur lätt tryck.

### GLID

1. Värm in lager med **CH6X** låt kallna sickla och borst för slitstyrkan.
2. Spraya på **CH8XL Liquid**, låt torka. Applicera vid en temperatur över 10°C. Var noga med att det torkar minst 15 minuter.
3. Avsluta med SWIX blå nylon poleringsborste.

### FÄSTE

1. Rugga fästzonen med slippapper #100 (SWIX T330 el. T0011).
2. Värm på ett lager **VG35** grönt grundvax. Låt kalna
3. Värm in ett lager **V30** blå burk.
4. Lägg 4-6 tunna lager **V45** lila burk.
5. Kan vara bra att ta med på turen.  
**V50** vid bakhalt, skrapa och kloss

### SKIN-SKIDOR

Skall Du åka med **skin-skidor**, rengör först med **N16 Skin Cleaner**. därefter impregnerar du skin-ytan med **N15 Skin Care**.

Vi återkommer med en uppdaterad prognos på fäste imorgon.

**LYCKA TILL!**

## SWIX FLUOR FREE WAX TIPS VASALOPPET

**FOR SUNDAY MARCH 03, 2019**

This whale tip is based on weather forecasts from smhi and on previous testing. It is predicting snow from night and out all day. Based on previous experience, there is no need for adhesive in these conditions

### TEMPERATURES

Sälen	kl. 08.00	-4°C
Evertsberg	kl. 11.00	-3°C
Mora	kl. 14.00	-2°C

### STRUCTURE

**Stone ground skis:** Fine to medium structure. Remember to use hand structure on stone ground skis for better glide.

**SWIX Structure Tool:** 1.0 mm linear structure.

### GLIDE

1. Iron in one layer of **CH6X** Let cool off. Iron in once more and let cool off. Scrape off with a Plexi Scraper, and brush with a SWIX Bronze or Steel Brush.
2. Spray on **CH8XL Liquid** and let dry for at least 15 minutes. Apply the product in temperatures above 10°C. To obtain the best performance it's important to allow the wax film to dry entirely.
3. Finish with the SWIX Blue Nylon Polish Brush.

### GRIP

1. Sand (rub) the grip zone area with #100 grit silicon sandpaper (Swix T330 or T0011).
2. Iron in one layer of **VG35** Green Base Binder. Let cool off.
3. Iron in one layer of **V30** Blue Grip Wax. Let cool of.
4. Apply 4-6 thin layers of **V45** Purpel Grip Wax. Smooth carefully out between each layer.
5. Can be good to bring along the tour.  
**V50** if it's slippery, scraper and block

### SKIN SKIS

If you are using **skis with integrated skins** we recommend to clean the skins with **N16 Skin Cleaner** and then use **N15 Skin Care** to improve the skins glide properties.

**We wish everybody a nice trip!**



Swix Racingservice Norge // Swix Sverige

